


Part List for Limit Switch Box ITS100



| Ref.no. | Description | Quantity |
|---------|-----------------|----------|
| 1 | Body | 1 |
| 2 | Bush | 1 |
| 3 | Cover | 1 |
| 4 | Indicator | 1 |
| 5 | Cover Indicator | 1 |
| 6 | Shaft | 1 |
| 7 | Spring | 2 |
| 8 | Space washer | 1 |
| 9 | Cam outer | 2 |
| 10 | Cam inner | 1 |
| 11 | Support ring | 1 |
| 12 | Bracket | 1 |
| 13 | Screw + washer | 4 |
| 14 | Screw | 4 |
| 15 | Screw + washer | 4 |
| 16 | Screw | 2 |
| 17 | Spring pin | 2 |
| 18 | Circlip | 2 |
| 19 | O-ring | 1 |
| 20 | O-ring | 1 |
| 21 | Terminal block | 1 |
| 22 | O-ring | 1 |
| 23 | Limit Switch | 2 |